

exchanger on the top or bottom side of the unit.

test: TEST-HAR-0049-01

date: engineer: 7.7.16 *status:* Done Cody Badger

history:

7.7.16 First run

Heat Exchanger Inlet Side Selection

system:

Brewbot Heat Exchanger

part: test: brew:

data:

Inlet Selection

procedure:

N/A in Trello

observations:


https://trello.com/c/LP4cC9IT

documentation:

summary:

At the test points used in this test, the heat exchanger has an effectiveness of 93% when the wort enters from the bottom side, and 64% when it enters from the top. To fully characterize the HX, we should test a wider range of input parameters (water temp, water flowrate).

This initial test is to determine if the wort in port should enter the heat



Due to the low flow (resulting in low HX pressure) nature of the cooling system, all of the channels in the heat exchanger do not fill with wort when filled from the top side. I suspect that this issue may be negligible at higher pressures, as the fluid being coold would be forced into all channels.

conclusions:

The wort should enter the HX on the bottom (low) side fo the HX, as in Setup #2 to the left.

Further testing is recommended.



test: TEST-HAR-0049-01 aate: engineer:

date: system:

7.7.16 Cody Badger Brewbot

part: test: Heat Exchanger **Inlet Selection** 

N/A

additional information:

Heat Exchanger Inlet Side Selection

brew:

Flow Name	Volume	Time (s)	Temp (°C)	Flowrate	Flowrate	Qdot (W)	Effectiven
	(L)			(L/s)	(kg/s)		ess
Cold Flow	10	53	15	0.189	0.189	-	-
Hot Flow	1	26	57	0.038	0.038	-	-
Cooled Hot Flow - Hot in on bottom	10	275	18.1	0.036	0.036	5913	93%
Heated Cold Flow - Hot in on bottom	-	-	23.2	-	-	6467	-
Cooled Hot Flow - Hot in on top	10	277	30.2	0.036	0.036	4044	64%
Heated Cold Flow - Hot in on top	-	-	20.4	-	-	4259	-



test: TEST-HAR-0049-01

date: enaineer:

7.7.16 Cody Badger Brewbot

part: test:

brew:

**Heat Exchanger** Inlet Selection N/A

Procedure:

system:

Heat Exchanger Inlet Side Selection

**Procedure** 

- 1. Fix the Cold in flow to the bottom of the HX.
- 2. Measure flowrate on both hot and cold side flows.
- 3. Measure temperature of both hot and cold side flows.
- 4. Cool HX with cold flow, attach hot flow, and fill 10L in a bucket while recording the time, final temperature, and average temperature of the cold flow.
- 5. Repeat steps 1-4 with the Cold\_in flow to the top of the HX.